

HUGHES BOX BLIND

ASSEMBLY INSTRUCTIONS FOR HP-67000

Note: It will take **two (2) people** to assemble this box blind.

Hughes Products Company, Inc. assumes no liability for injury or damage to persons or property resulting from the use of the Hughes Box Blind. The Hughes Box Blind must be assembled, installed, anchored, and used with care, caution, and common sense. Anchoring the Hughes Box Blind is the **owner's responsibility**.

You must read all instructions before starting assembly!

(When referring to wall letters(A,B,C,&D), all walls are identical except when referring to Wall D, which is the panel with your door cut out.)

TOOLS REQUIRED FOR ASSEMBLY:

Cordless drill
Phillips head drill bit

Measuring tape
Adjustable wrench or pliers

PARTS LIST:

(1) Roof
(1) Package with screws, nuts, & bolts (extras included in case of losing them)
(3) Walls with windows cut out
(1) Wall with window and door cut out

ITEMS NEEDED (see page 3)

(1) 2 x 4 x 49" for wall support #1
(2) 2 x 4 x 45.5" for wall support #2 & #3
(1) 2 x 4 x 42" for wall support #4

****When referring to figure IV, platform for flooring is not included. We recommend using a 4 x 4 ft, 0.5" thick, piece of plywood as flooring.**

*****DOOR SUPPORT (optional): (2) Vertical 2 x 4's. (Picture available on company website).**

INSTRUCTIONS:

- 1) With wall panels A & B vertical, one person stands on the inside with nuts & the other on the outside with the screws (8-32 x 3/4) (See Fig.1). Overlap the offset corner of Panel A with Panel B. Using the predrilled holes, starting at the top insert screws (8-32 x 3/4) one at a time down the edge of Panel B. **DO NOT PUT A SCREW IN THE 3RD HOLE UP FROM THE BOTTOM. A WOOD SCREW, #10 X 1", WILL GO THERE AT A LATER TIME DURING ASSEMBLY. DO NOT PUT A SCREW IN THE BOTTOM HOLE IF YOU ARE ADDING FLOORING UNTIL THE END OF ASSEMBLY.** Make sure panels are tight against each other before you insert each screw.
- 2) Repeat above steps on panels A & C. Now attach panel D (door panel) to panels B & C.
- 3) Place roof over the top of the panels. With one person inside and one out, insert screws (8-32 x 3/4) from the outside into predrilled holes along the bottom edge of roof panel. Again make sure roof panel is tight against the wall panel before you insert each screw. **Note: Some screw holes may not line up. In the event this happens, re-drill holes from the outside of the roof to line up with holes in the panels.**
- 4) On the inside of the box blind, insert 2 x 4 #1 into the horizontal groove in the side Panel D, just above the door and below the window (see Fig. II). Make sure the 2 x 4 #1 is pushed tight against the right side lip of Panel D. Now from the outside, insert screws #10 x 1 into the 2 x 4 through predrilled holes of Panel D. On the CORNER, make sure Panels D & B are tight against each other before you secure the screw.
- 5) Install 2 x 4 #2 into Panel B just as instructed above. Make sure 2 x 4 #2 is pushed tight against the side of 2 x 4 #1. Insert screws #10 x 1 from outside.
- 6) Install 2 x 4 #3 into Panel C just as instructed above. Make sure 2 x 4 #3 is pushed tight against the side of 2 x 4 #1. Insert screws #10 x 1 from outside.
- 7) Install 2 x 4 #4 into Panel A just as instructed above. Make sure 2 x 4 #4 is tight against the sides of 2 x 4 #2 and #3. Insert screws #10 x 1 from outside. Now from the inside of the box blind, connect the 2 x 4's to each other in corners using #8 x 1 3/4" wood screws provided (see Fig. III).

If inserting flooring (optional):

8) If inserting flooring into your box blind, lay it on top of lip on inside of box blind bottom. Insert 8-32 x 3/4" screws into the bottom predrilled hole on each panel corner.

If you would have any problems with this product, please contact HUGHES PRODUCTS COMPANY, INC. at 336-769-3788. Please do not contact the merchant where you purchased the blind.

Optional 5' extension for box blind

Item= HP-67051

Optional 10' extension for box blind

Item= HP-67052

*****Call company for pricing.**

(Pictures available on website)

HUGHES PRODUCTS COMPANY, INC.

241 Emily Ann Dr.

Winston Salem, NC 27107

336-769-3788 Fax: 336-769-3792

Email us: hughesproductscs@yahoo.com

